

# CLEVER TRIMS & ACCESSORIES

*Everything you need to complete your flooring installation*



✓ Quality   ✓ Style   ✓ Value

*Fashion in flooring*



# Discover Clever Trims & Accessories

*For a professional flooring installation follow best practices.*

## **Expansion & Contraction**

Natural movement of your floors is to be expected. Expansion and contraction are common and continuous factors of all floors. Various conditions including and not limited to temperature, moisture, and humidity all impact the performance and life of the floor and quality of flooring installation, regardless of the type and construction of flooring material used.

Gaps are left around the edges of the room including fixtures and cabinetry to accommodate the natural movement of your floors. These gaps are referred to in the industry as Expansion Gaps.

The expansion gaps around the perimeter of the room including fixtures and cabinetry are not visible as they are finished in style with the use of Scotia, Stairnoses, and Trims.

## **Room Size or Room Transition**

Any large size room that exceeds the raft size recommended for the floor type you choose or where the floor will transition to a new space/room, will require the installation of a H trim. A H trim has two separate parts: a base plate and the H top.

## **Finishing or Ends**

Use a C Trim to finish off against tiled areas, timber or metal doors and window tracks. A C Trim can also be used around cabinetry instead of Scotia. It comes in two separate parts: a base plate and a C top.

## **Height Variances and changes between floor types**

The Universal Cover (2 pieces) creates a seamless connection or a ramp. This helps to avoid trip hazards between the height variance created where the floorboards meet with carpet or other flooring types.

## **Design & Application of Trims**

For use in residential, office and light commercial applications. Trims are not recommended for areas that will have stock trolleys or experience high/heavy loads rolling over. All Clever Trims are suitable for Classic Laminate, European Oak, Australian Timbers, Hybrid, Hydro and Bamboo Flooring.

To avoid issues after flooring installation such as squeaking, bouncing, cupping or boards exposed from under trims, scotia or skirting it is vital that you plan, prepare and follow recommendations.

For more information read our product guidelines and warranty terms and conditions available from the Clever Choice website [www.cleverchoice.com.au](http://www.cleverchoice.com.au) or your place of purchase.



# Contents

## TRIMS

## PAGE

H Trim Top	4
C Trim Top	5
C and H Trim Base	6
Universal Cover	7
L Angle Small	8
L Angle Large	9
U Channel	10
Flat Cover	11

## SCOTIA

## PAGE

Classic/Hydro	12
Hybrid	14

## STAIRNOSE

## PAGE

Classic/Hydro	15
Hybrid	17
Custom	18

## ACCESSORIES

## PAGE

Slip Resistant Products	19
-------------------------	----

## INSTALLATION GUIDE

## PAGE

Trims and Accessories	20
-----------------------	----

# Clever Profile H Trim Top



Silver 782521



Titanium 782522



Black 782523



Ash Grey 782524



Cloud 782525



Light Grey 782526



Blackbutt 782527



Natural 782528



Spotted Gum 782529



Ironbark 782530



Kempas 782531



White Oak 782532

## Dimensions


L2700mm x W38mm x H6mm

## Uses

For expansion gaps at raft tolerances or between rooms and doorway transitions.

## Fixing

The H Trim Top is slotted over the base



**1 of 2 parts. Order the base separately by height.**

# Clever Profile C Trim Top



Silver 782421



Titanium 782422



Black 782423



Ash Grey 782424



Cloud 782425



Light Grey 782426



Blackbutt 782427



Natural 782428



Spotted Gum 782429



Ironbark 782430



Kempas 782431



White Oak 782432

## Dimensions

L2700mm x W25mm x H6mm

## Uses

To transition to other floor coverings or vertical surfaces or as an end for a neat and professional finish

## Fixing

The C Trim Top is slotted over the base



**1 of 2 parts. Order the base separately by height.**

# Clever Profile C & H Trim Base



6mm Base 782606



8mm Base 782608



10mm Base 782610






12mm Base 782612



14mm Base 782614



20mm Base 782620



## Dimensions

L2700mm

## Uses

As the base for C Top and H Top refer to page 4 and 5 for details

## Fixing

The base is installed prior to the flooring installation and fixed to the subfloor using screws and/or builders adhesive



**1 of 2 parts. Order the tops separately by colour.**



# Clever Trim Universal Cover



Silver 782321



Titanium 782322



Black 782323



Ash Grey 782324



Cloud 782325



Light Grey 782326



Blackbutt 782327



Natural 782328



Spotted Gum 782329



Ironbark 782330



Kempas 782331



White Oak 782332

## Dimensions

L2700mm x W45mm

## Uses

To connect different floor coverings or as a small ramp for surfaces of uneven height

## Fixing

With screws and the channel cover is inserted for a seamless and professional finish



**Two Pieces. Base and Channel Cover**

# Clever Profile L Trim Small



Silver 782121



Titanium 782122



Black 782123



Ash Grey 782124



Cloud 782125



Light Grey 782126



Blackbutt 782127



Natural 782128



Spotted Gum 782129



Ironbark 782130



Kempas 782131



White Oak 782132

## Dimensions

L2700mm x W25mm x H10mm

## Uses

Transition to other floor coverings or vertical surfaces or to use as edging for staircases, and landings. Provides a seamless finish.

## Fixing

With builders adhesive





# Clever Trim L Trim Large



Silver 782221



Titanium 782222



Black 782223



Ash Grey 782224



Cloud 782225



Light Grey 782226



Blackbutt 782227



Natural 782228



Spotted Gum 782229



Ironbark 782230



Kempas 782231



White Oak 782232

## Dimensions

L2700mm x W30mm x H20mm

## Uses

Transition to other floor coverings or vertical surfaces or to use as edging for staircases, and landings. Provides a seamless finish.

## Fixing

With builders adhesive



# Clever Trim U-Channel



## Silver U-Channel

6.5mm	782721
8.5mm	782821
10.5mm	782921
12.5mm	783021
15mm	783121

## Titanium U-Channel

6.5mm	782722
8.5mm	782822
10.5mm	782922
12.5mm	783022
15mm	783122



### Dimensions


L2700mm

### Uses

Designed as 1 piece to transition to other flooring or vertical surfaces or as an end for a neat and seamless finish.

### Fixing

With screws and/or builders adhesive



# Clever Trim Flat Cover



Silver 783221



Titanium 783222



Black 783223



Ash Grey 783224



Cloud 783225



Light Grey 783226



Blackbutt 783227



Natural 783228



Spotted Gum 783229



Ironbark 783230



Kempas 783231



White Oak 783232

## Dimensions

L2700mm x W45mm

## Uses

This 1 piece Universal trim connects carpet to floorboards or as a small ramp for surfaces of uneven height

## Fixing

With exposed screws



**Single Piece**



# Clever Finish Scotia Classic



Alaska 11960201



Hawaii 11960202



Miami 11960203



Helena 11960204



Lincoln 11960205



Kansas 11960206



New York 11960207



Nashville 11960208



Cleveland 11960209



Black Magic 11960210



Antique Teak 11960211



Aqua Brusbox 11960212



Aqua Blackbutt 11960213



Aqua Spotted Gum 11960214



White 11980100



Gloss Brushbox 11980101



Gloss Cypress Pine 11980102



Gloss Spotted Gum 11980103

# Clever Finish Scotia Classic



Gloss Blackbutt 11980104



Gloss Jarrah 11980105



Antique Brass 11980106



Matt Blackbutt 11980107



Matt Spotted Gum 11980108



Aged Teak 11980109



Seashell 11980110



Moonlight 11980111



Silver Grey 11980112



Iron Grey 11980113



White Oak 11980114



Silky Silver 11980115



Barrelwood 11980116



Barnyard Grey 11980117



Le Sands 11980118

**Dimensions** L2400mm x W23mm x H23mm

## Fixing

Can be fixed using a brad nailer and/or builders adhesive.

## Uses

Frames the perimeter of your rooms, fixtures and cabinetry to cover expansion gaps. Can act as a decor element to the overall design of your rooms.

# Clever Finish Scotia Hybrid



Athens 11940361



Vienna 11940362



Kande Oak 11940363



Milan 11940364



Florence 11940365



Barcelona/Winterfalls 11940366



Paris/Grey Forest 11940367



Venice 11940368



NSW/Coastal Blackbutt 11940369



NSW/Coastal Spotted Gum 11940370



Cannes/Coastal Breeze 11940371



Berlin/Wheat Land 11940372



Prague/Sandy Rock 11940373



Budapest 11940374



Dublin/Black Sea 11940375

## Dimensions

L2400mm  
W15mm  
H15mm

## Uses

Frames the perimeter of your rooms, fixtures and cabinetry to cover expansion gaps. Can act as a decor element to the overall design of your rooms.

## Fixing

Can be fixed using a brad nailer and/or builders adhesive.





# Clever Finish Stairnose Classic



Alaska 12960201



Hawaii 12960202



Miami 12960203



Helena 12960204



Lincoln 12960205



Kansas 12960206



New York 12960207



Nashville 12960208



Cleveland 12960209



Black Magic 12960210



Antique Teak 12960211



Aqua Brusbox 12960212



Aqua Blackbutt 12960213



Aqua Spotted Gum 12960214



Gloss Brusbox 12980101



Gloss Cypress Pine 12980102



Gloss Spotted Gum 12980103



Gloss Blackbutt 12980104

# Clever Finish Stairnose Classic



Gloss Jarrah 12980105



Antique Brass 12980106



Matt Blackbutt 12980107



Matt Spotted Gum 12980108



Aged Teak 12980109



Seashell 12980110



Moonlight 12980111



Silver Grey 12980112



Iron Grey 12980113



White Oak 12980114



Silky Silver 12980115



Barrelwood 12980116



Barnyard Grey 12980117



Le Sands 12980118



**Dimensions** L2400

## Fixing

Install floorboards on the riser first, using builders' adhesive. Cut the stairnose to fit over the riser. Cut the boards and glue into place to finish the tread.

## Uses

Protrudes a little over the edge providing extra space for you to place your feet on. For an elegant and masterful finish that adds value to your home.

# Clever Finish Stairnose Hybrid



Athens 12940361



Vienna 12940362



Kande Oak 12940363



Milan 12940364



Florence 12940365



Barcelona 12940366  
Winterfalls 12940905



Paris 12940367  
Grey Forest 12940902



Venice 12940368



NSW Blackbutt 12940369  
Coastal Blackbutt 12940907



NSW Spotted Gum 12940370  
Coastal Spotted Gum 12940908



Cannes 12940371  
Coastal Breeze 12940901



Berlin 12940372  
Wheat Land 12940903



Prague 12940373  
Sandy Rock 12940904



Budapest 12940374



Dublin 12940375  
Black Sea 12940906

**Dimensions** L2400

## Fixing

Install floorboards on the riser first, using builders' adhesive. Cut the stairnose to fit over the riser. Cut the boards and glue into place to finish the tread.

## Uses

Protrudes a little over the edge providing extra space for you to place your feet on. For an elegant and masterful finish that adds value to your home.





# Clever Finish Stairnose Custom

Clever Choice arranges for your stairnosing to be custom made for any Clever Choice flooring product.

This is especially important for products with high natural colour and feature variations such as Australian Timber Species, European Oak and Bamboo ranges.

- Produce stairnosing from the same batch for a harmonious colour match
- Order custom stairnosing across all Clever flooring products including Laminate, Hydro, Hybrid, Bamboo, Oak, Australian Timbers
- It takes 5-7 days from the date of your order to turn-around a custom stairnose request



*Stairnosing adds value, creates a professional finish and a beautiful feature in your home or office.*

# Clever Finish Slip Resistant Products



## Anti-Slip Tape

Anti-slip tape can be used on a variety of surfaces to prevent falls or slips around the home or office. Anti-slip tape is manufactured from a unique combination of aluminum oxide and a thick plastic carrier to provide a flexible and durable non-slip solution.

- Easy to install, just peel and stick
- P5 slip resistance rating (AS1428:2013)
- Uniquely flexible allows for a bend in excess of 90°
- Withstands temperatures below -30°C and up to 120°C

Available to order from Clever Choice:

- Clear Anti-Slip Tape 50mm x 18m 781101
- Black Anti-Slip Tape 50mm x 18m 781102

## Bona Traffic HD Anti-Slip

Using advanced polymer technology, Bona Traffic HD was developed to give uncompromising resistance to scratches, scuff marks and chemical spills whilst being sustainable with regard to the environment. It is formulated to meet the highest standards for slip resistance in commercial areas, staircases, or other situations with an increased risk of spillage.

- Clear, non-yellowing finish
- Enhances the natural beauty of a timber floor
- High durability and extreme scratch resistance
- Increases protection from accidental slips
- Very low odour
- P4 (low risk of slipping) according to AS 4586:2013



- Bona Anti-Slip HD Coating 5L

- Bona Application Pack

*Improve the slip resistance to stair treads, entrance and exit points.*



## Tools and PPE equipment

Be prepared for every installation and always have the right tools and Personal Protective Equipment available and in use to complete the flooring installation or task being performed. Most importantly keep yourself and others around you safe!



### **C Trim**

1. Sweep and clean the subfloor
2. Install underlay through the floor
3. Measure and cut the C Trim and Base to length
4. Position the Base 1-2mm off any solid objects and predrill holes for screws
5. Screw/glue the base into place
6. Install your flooring, leaving an 8mm space between the boards and the centre piece of the trim
7. Wipe and clean the surface of the board before setting the trims in place
8. Fix the top plate of the C trim, to the base with rubber hammer. Apply builders' adhesive into the channel for extra strength, stability and reduction in noise. Ensure the top plate is not too tight restricting natural movement.



### **H Trim**

1. Sweep and clean the subfloor
2. Install underlay through the floor
3. Measure and cut the H Trim and Base to length
4. Position the Base in all doorways and/or Raft size perimeters and predrill holes for screws
5. Screw/glue the base into place
6. Install your flooring, leaving an 8mm space between the boards and the centre piece of the trim
7. Wipe and clean the surface of the board before setting the trims in place
8. Fix the top plate of the H trim, to the base with rubber hammer. Apply builders' adhesive into the channel for extra strength, stability, and noise reduction. Ensure the top plate is not too tight restricting natural movement.








## Universal Cover

1. Measure and cut the Universal Cover to length
2. Wipe and clean the surface of the board before setting the trims in place
3. Position the trim and predrill holes for screws, leave allowances for natural movement
4. Screw the Universal Cover into place directly into the subfloor. Ensure the trim is not too tight restricting natural movement
5. Fix the top plate of the Universal Cover, to the base with rubber hammer. For extra strength and reduction in noise, apply builders adhesive into the channel before installing the top plate



## L Trim

1. Measure and cut the L Trim to length
2. Wipe and clean the surface of the board before setting the trims in place
3. Apply builders' adhesive to the underside of the L Trim
4. Fix the L Trim tight to the edge of the board
5. Wipe off any excess glue



## Flat Cover

1. Measure and cut the Flat Cover to length
2. Wipe and clean the surface of the board before setting the trims in place
3. Position the trim and predrill holes for screws, leave allowances for natural movement
4. Screw the Flat Cover directly into the subfloor, ensure the trim is not too tight restricting natural movement.







## U Channel

1. Sweep and clean the subfloor
2. Install underlay through the floor
3. Measure and cut the U Channel to length
4. Position the U Channel directly against the solid object/s and predrill holes for screws
5. Screw/glue the U Channel into place
6. Wipe and clean the surface of the board before setting the trims in place
7. Install your flooring, sliding the boards under the trim, ensuring to leaving an 8mm space between the boards and the end of the trim



## Stairnose

1. Remove any additional coverings i.e. carpet, nails, vinyl off the staircase
2. If the substructure has a bullnose, then you will need to either cut it off or pack out the riser
3. Clean the substructure free of dirt or debris
4. Cut and install floorboards on the riser first, using builders' adhesive to glue the boards in place
5. Then cut the stairnose to fit over the riser. Cut the floorboards to finish off the rest of the tread and fix using builders' adhesive to glue the boards in place
6. Repeat this process for each stair, starting at the bottom, working your way up

*Please note: Underlay is not to be used on the installation of stairs*



## For a floor that functions, finish it well...

Your flooring purchase is not complete without flooring trims, scotia, stairnosing, and underlay. For optimum performance and to avoid post installation issues give your floor that finished, professional, neat, and tidy look, whilst concealing those all important expansion gaps and cut edges for the natural expansion and contraction of your Clever floors.



## **Scotia**

1. Measure and cut the scotia to length around the perimeter of the installed flooring
2. Check that the correct perimeter gap & coverage has been left. Make any adjustments for compliance prior to fixing the scotia
3. Sweep and clean the surface before setting the scotia in place
4. Fix the scotia to the wall/skirting using brad nails and/or builders' adhesive

DO NOT fix the scotia to the flooring and DO NOT silicon the bottom of the scotia or skirting to the floor. Both of these practices will restrict the natural movement and cause performance issues.



## **Underlay**

1. Remove any old floor coverings i.e. carpet, tiles, vinyl, underlay, smooth edge etc
  2. Check your subfloor meets Australian standards for level and moisture content
  3. The subfloor needs to be clean and free of loose materials and contaminants
  4. Use a laser level or 2m straight edge. Check for flat/smooth/level within tolerance no greater than 2mm over 2m
  5. Correct any changes in levels by either diamond grinding the surface of the slab, sanding the surface of the timber subfloor and/or using a levelling compound to fill in low spot/s
  6. After levelling, wait the manufactures recommended time to allow the compound to dry completely before laying your underlay, to prevent moisture related issues
  7. Check concrete slabs have been cured with the moisture content being less than 5% moisture and relative humidity below 75%. Suspected dampness in a concrete slab, must be checked by a moisture meter using "plugs" drilled into the slab
  8. Check our Clever Choice product guidelines for full details of correct installation practices
  9. Sweep and clean the sub floor surface before placing the underlay on the subfloor
  10. For floating installation: Unroll the Underlay across the length of your room, the silver or plastic side facing down. Cover the entire floor and 20mm up the walls with the underlay. Seal underlay joins with attached tape. Lay your flooring boards over the underlay
  11. For dual bond: apply builders adhesive using the manufactures approved notch trowel and then unroll the underlay across the length of the room. Seal underlay joins with attached tape. Apply builders adhesive using the manufactures approved notch trowel and then lay floor boards
  12. Ensure you keep the underlay straight, flat and gap-free
  13. When installing your trims and scotia, trim off any excess underlay.
- Clever Silver, Comfort, Sound, and Acoustic 5 are floating installation only
  - 5mm Rubber, 3mm Cork, and 5mm Cork are suitable for floating and dual-bond installation
  - For added moisture protection extra tape can be used to seal joins







*Clever Trims*



Oak Luxury Tea Light

t 07 5526 7399  
e sales@cleverchoice.com.au  
[www.cleverchoice.com.au](http://www.cleverchoice.com.au)

